



# Apple Powerbook 5300 Battery Replacement

Installing/replacing a Powerbook 5300 battery.

Written By: Alex Wineteer



## INTRODUCTION

This guide will show you how to install a Powerbook 5300 battery.

## Step 1 — Battery



- Position the Powerbook towards you with the monitor closed.
- Press the battery removal latch located on the right side of the front panel.
- Gently slide the battery out.

⚠ The keyboard, front pane, and hard drive are connected to the laptop's logic board via a ribbon cable. Lift up slowly on each component with one hand and disconnect the ribbons from their ports on the logic board.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-22 10:22:32 PM.